

## 1005 R Strike



## 1015 R Strike




Fig 1:





Fig 2:



## Reversible Strikes

To provide the practical option of non handed strikes.

For Chant latches and locks, the strikes are designed to protrude a minimal amount from the outside face of the door jamb to provide a cleaner visual appearance, without the standard bent lip protruding beyond the jamb.

This requires "architraves" or "casings" to be placed away from the door opening, clear of the latch bolt. This is an important detail in the initial design concept of the project in relation to the construction of the wall and door frame. (see figure 1 below)

Alternatively, the strike can be made to not protrude further than necessary from the jamb, but sufficient to protect the jamb from the latch bolt. (see figure 2 below)

In all cases, these strikes must be carefully site measured to be minimum 2mm past the edge of the jamb or door frame. They require the lock or latch to be positioned accurately in the centre of the door for correct latching, or if offcentre, carefully measured and specified.

## Mortise Lock and Latch Strikes

Made from 3mm brass. The leading edge has a 1mm chamfer on each side for the latch bolt to slide past.

For Chant Mortise Locks 1000 to 1005. Specify 1005 R, offset dimension and finish.

For Chant Mortise Latches 1011 to 1013. Specify 1015 R, offset dimension and finish.