


# Plate Specification - Oval Locks and Plates

## Guide for ordering

① K30	② 32	③ 0/6	④ P1-C	⑤ R	<b>ORDER CODE</b>
Lock/Plate Series	Plate Width	Function: 0 / 6 *Specify (F) if Fixed (e.g 0F/6)	Plate Profile and Edge detail	Handing	<b>K30 - 32 - 0/6 - P1-C - R</b>



### ① Lock & Plate Length Pairing (Select lock & plate series e.g. K20)

Passage function - Long plates - Levers require lock reference information as this detail determines the lever position on the plate. Specify function codes '0/5' for the function itself.

Lock	Centres 'P'	Plate Series Options
K Legge 990, Lockwood 3572	63.5mm	20 / 30
L Legge 995, Lockwood 5582	90mm	35 / 41 / 60

Series	Length 'L'	Lever Position 'Y'	Fixing Centres 'C'
20	175mm	55	144
30	191mm	61.5	159
35	190mm	52.5	159
41	220mm	82.5	189
60	300mm	120	269

### ② Plate Width Options




### ③ Select plate function (e.g order 0/6 where '0' = Passage outside & '6' = Cylinder inside)

Specify (F - Fixed) after the plate function if you required a fixed lever, or stipulate in the 'handing' field of the Order Form.

Outside / back fix plates concealed fixing					Inside / surface fix plates semi concealed fixing		
0	1	2	3	4	5	6	8
Passage	Cylinder	Recess E-Turn	E-Turn	Blank Cylinder	Passage	Cylinder	Thumb Turn

### ④ Select edge detail & profile

Select from list, Standard or 'VED' sheet



### ⑤ Specify handing

L for Left hand and R for Right hand.

Refer to the Chant handing sheet for more information

